



Symbol	Wymiary				Nakrętka hydrauliczna	Nakrętka KM
	d1	d	B1	B2		
Kolumna1	Kolumna2	Kolumna3	Kolumna4	Kolumna5	Kolumna6	Kolumna7
AH 308	35	40	29	32		KM 9
AH 2308	35	40	40	43		KM 9
AH 309	40	45	31	34	HMV 10 E	KM 10
AH 2309	40	45	44	47	HMV 10 E	KM 10
AH 2313	60	65	61	64	HMV 14 E	KM 14
AH 313	60	65	42	45	HMV 14 E	KM 14
AH 314	65	70	43	47	HMV 15 E	KM 15
AH 315	70	75	45	49	HMV 16 E	KM 16
AH 316	75	80	48	52	HMV 18 E	KM 18
AH 24122	105	110	82	91	HMV 23 E	KM 23
AH 24124	115	120	93	102	HMV 26 E	KM 26
AH 24126	125	130	94	104	HMV 28 E	KM 28
AH 24024	115	120	73	82	HMV 25 E	KM 25
AH 24026	125	130	83	93	HMV 27 E	KM 27
AH 24128	135	140	99	109	HMV 30 E	KM 30
AH 24028	135	140	83	93	HMV 29 E	KM 29
AH 24030	145	150	90	101	HMV 31 E	KM 31
AH 24130	145	150	115	126	HMV 32 E	KM 32
AH 3232	150	160	124	130	HMV 34 E	KM 34
AH 3032	150	160	77	82	HMV 34 E	KM 34
AH 2332	150	160	140	146	HMV 34 E	KM 34
AH 3132	150	160	103	108	HMV 34 E	KM 34
AH 24032	150	160	95	106	HMV 34 E	KM 34
AH 24132	150	160	124	135	HMV 34 E	KM 34
AH 3234	160	170	134	140	HMV 36 E	KM 36
AH 3134	160	170	104	109	HMV 36 E	KM 36
AH 3034	160	170	85	90	HMV 36 E	KM 36
AH 2334	160	170	146	152	HMV 36 E	KM 36
AH 24034	160	170	106	117	HMV 36 E	KM 36
AH 24134	160	170	125	136	HMV 36 E	KM 36
AH 3136	170	180	116	122	HMV 38 E	KM 38
AH 2336	170	180	154	160	HMV 38 E	KM 38

AH 3036	170	180	92	98	HMV 38 E	KM 38
AH 2236	170	180	105	110	HMV 38 E	KM 38
AH 3236	170	180	140	146	HMV 38 E	KM 38
AH 24036	170	180	116	127	HMV 38 E	KM 38
AH 24136	170	180	134	145	HMV 38 E	KM 38
AH 2238	180	190	112	117	HMV 40 E	KM 40
AH 3038	180	190	96	102	HMV 40 E	KM 40
AH 2338	180	190	160	167	HMV 40 E	KM 40
AH 3238	180	190	145	152	HMV 40 E	KM 40
AH 3138	180	190	125	131	HMV 40 E	KM 40
AH 24038	180	190	118	131	HMV 40 E	KM 40
AH 24138	180	190	146	159	HMV 40 E	KM 40
AH 3240	190	200	153	160	HMV 44 E	HM 3044
AH 3140	190	200	134	140	HMV 44 E	HM 3044
AH 3040	190	200	102	108	HMV 42 E	HM 42 T
AH 24040	190	200	127	140	HMV 42 E	HM 42 T
AH 24140	190	200	158	171	HMV 42 E	HM 42 T
AH 2340	190	200	170	177	HMV 44 E	HM 3044
AHX 310	45	50	35	38	HMV 11 E	KM 11
AHX 2310	45	50	50	53	HMV 11 E	KM 11
AHX 311	50	55	37	40	HMV 12 E	KM 12
AHX 2311	50	55	54	57	HMV 12 E	KM 12
AHX 312	55	60	40	43	HMV 13 E	KM 13
AHX 2312	55	60	58	61	HMV 13 E	KM 13
AHX 2314	65	70	64	68	HMV 15 E	KM 15
AHX 2315	70	75	68	72	HMV 16 E	KM 16
AHX 2316	75	80	71	75	HMV 18 E	KM 18
AHX 317	80	85	52	56	HMV 19 E	KM 19
AHX 2317	80	85	74	78	HMV 19 E	KM 19
AHX 318	85	90	53	57	HMV 20 E	KM 20
AHX 3218	85	90	63	67	HMV 20 E	KM 20
AHX 2318	85	90	79	83	HMV 20 E	KM 20
AHX 319	90	95	57	61	HMV 21 E	KM 21
AHX 2319	90	95	85	89	HMV 21 E	KM 21
AHX 320	95	100	59	63	HMV 22 E	KM 22
AHX 3120	95	100	64	68	HMV 22 E	KM 22
AHX 3220	95	100	73	77	HMV 22 E	KM 22
AHX 2320	95	100	90	94	HMV 22 E	KM 22
AHX 322	105	110	63	67	HMV 24 E	KM 24
AHX 3122	105	110	68	72	HMV 24 E	KM 24
AHX 2322	105	110	98	102	HMV 24 E	KM 24
AHX 3222	105	110	82	86	HMV 24 E	KM 24
AHX 3124	115	120	75	79	HMV 26 E	KM 26
AHX 3224	115	120	90	94	HMV 26 E	KM 26
AHX 2324	115	120	105	109	HMV 26 E	KM 26
AHX 3024	115	120	60	64	HMV 26 E	KM 26
AHX 3126	125	130	78	82	HMV 28 E	KM 28
AHX 2326	125	130	115	119	HMV 28 E	KM 28
AHX 3226	125	130	98	102	HMV 28 E	KM 28
AHX 3026	125	130	67	71	HMV 28 E	KM 28

AHX 3128	135	140	83	88	HMV 30 E	KM 30
AHX 3228	135	140	104	109	HMV 30 E	KM 30
AHX 2328	135	140	125	130	HMV 30 E	KM 30
AHX 3028	135	140	68	73	HMV 30 E	KM 30
AHX 2330	145	150	135	140	HMV 32 E	KM 32
AHX 3130	145	150	96	101	HMV 32 E	KM 32
AHX 3030	145	150	72	77	HMV 32 E	KM 32
AHX 3230	145	150	114	119	HMV 32 E	KM 32

